

## CONTROL BOX REPLACEMENT

## For GVM's and CIV's

## **Replacement Instructions**

For safety purposes, always wear protective boots, eyewear and any recommended shop safety items. To prevent accidents or injuries, always use a forklift or chain hoist when stated.

**Removal** of the Control Box:

- 1. Support the Control Box by attaching a large "C-Clamp" to the Column, at the base of the box.
- 2. Disconnect the Rear Cable by removing the Cotter Pin from the Rear Clevis. Allow the Cable to hang freely.
- Using a forklift or chain hoist, lift the Rear Cable up until the Front Cable has 1" of slack.
- 4. Remove the two ½" Bolts from the Pulley Box. A ladder may be necessary to perform this step.
- 5. Disconnect the Front Cable from the Clevis and using a Fork Lift or Chain Hoist, lift both the Counterweight and Pulley Box out of the Column. Set to the side.
- 6. Using a forklift or chain hoist on the Front Clevis, lift the Control Box from the Column.

## **Replacement** of the Control Box

To install a new or repaired Control Box, reverse the above procedure. Be certain to have a "C-Clamp" in place, before lowering a Control Box down the Column.

- 1. Replace the Control Box on the Column.
- 2. Replace the Counterweight and Pulley Box.
- 3. Connect the Front Cable to the Clevis.
- 4. Insert the two Bolts into the Pulley Box.
- 5. Reconnect the Rear Cable to the Rear Clevis and replace the Cotter Pin.
- 6. Remove the "C-Clamp and ensure that there is easy of motion of the Control Box, up and down, on the Column.

For any questions or concerns, please contact Galiso, Incorporated at 1-800-854-3789, or 970-249-0233.